


# Supplemental Support for Heavy Equipment

Tate Access Floors, Inc.  
7510 Montevideo Road  
Jessup, MD 20794  
Tel (410) 799-4200  
Fax (410) 799-4207



Additional pedestal  
(standard type) adjusted to  
support bottom of panel at  
point of load

PosiLock™ or stringer understructure system

## Notes

This support method is used for conditions where equipment loads will be in excess of the panel load rating

This method allows the equipment legs to be located anywhere on the panels

Equipment that rests on rails (or that had a continuous base) may be supported by putting supplemental pedestals around the equipment perimeter on 12" centers

This method can be used with either PosiLock™ or stringer understructure systems

Care should be taken when moving equipment into place, use spreader plates to help spread the load over the panels during move-in